



INSTALLATION AND OPERATING
MANUAL

FOR

SIMPLEX COMBO READER/READ HEAD

MODEL 1880	Part No. 710-0005-00
MODEL 1880E	Part No. 800-0006-00

Version 3/00

TABLE OF CONTENTS

SECTION 1 - GENERAL INFORMATION

1.1 INTRODUCTION	Page 3
1.2 DESCRIPTION	Page 3
1.3 SPECIFICATIONS	Page 4

SECTION 2 - INSTALLATION

2.1 INTRODUCTION	Page 5
2.2 UNPACKING AND INSPECTION	Page 5
2.3 INSTALLATION SUMMARY	Page 5
2.4 POWER REQUIREMENTS	Page 6
2.5 AC/DC POWER SELECTION	Page 7
2.6 POWER CONNECTIONS	Page 7
2.7 SIGNAL CABLING	Page 8
2.8 REMOTE ENABLE CABLING	Page 9
2.9 ANTENNA CONNECTIONS	Page 9
2.10 MOUNTING CONSIDERATIONS	Page 9
2.11 EXTERNAL INTERFERENCE	Page 10
2.12 WARRANTY	Page 10

If you are reading a pdf version of this manual you may notice page numbers and the above contents to be off by a page from time to time. The conversion to Acrobat has a tendency to move sections as the fonts do not translate perfectly.

SECTION 1 GENERAL INFORMATION

1.1 INTRODUCTION

This manual provides information pertaining to the installation and operation of the Model 1880 Combo Reader/Antenna, PCB only, (RFID, Inc. Part No. 710-0005-00) or Model 1880E (the E signifying enclosure) (RFID, Inc. Part No. 800-0006-00).

1.2 DESCRIPTION

The Model 1880 is a versatile, low powered Reader with an RF Antenna etched into its PCB thus combining the 2 operations of a Reader and an Antenna/Read Head into a single piece Combo Reader Antenna. The Model 1880 is ideally suited for integration into conveyor systems, Automated Storage and Retrieval Systems (AS/RS) and other RFID requirements in warehouse and factory applications.

The Combo Reader operates as both a transmitter and receiver. The Combo Reader provides a low-frequency electromagnetic field at 148 kHz to energize and activate an Electronic Transponder, or Tag, in the vicinity of the Antenna. Once the Tag is energized, it modulates its data back to the Combo Reader. The Combo Reader detects, amplifies and filters this modulation, translates the RF data signal into a digital format and relays it to the Interface unit for use by a host computer, process controller or display and storage device. The Interface of course translates the digital data into a computer understandable language, like serial.

The Combo Reader is simple to use and install. It requires no alignment or adjustment and can operate from different types of power sources. The unit may be mounted in a variety of ways to suit the particular application and equipment.

1.3 SPECIFICATIONS

Operating Frequency:	148 kHz +/-0.5% (transmit) 37 kHz (receive)
Tag Reading Distance:	Up to 18" (depending on Antenna, transponder and orientation)
Remote Enable:	5 mA, Opto-isolated
Signal Output:	75 ohms, balanced
Cabling to Interface:	Up to 5000 feet (with shielded twisted pair cable)
Connectors:	Angle entry terminal strips
Antenna:	TB3 - 1 and 3
Signal to Reader:	TB1 - 1 and 2
Remote Enable:	TB2 - 1 and 2
Power:	TB2 - 3, 4 and 5
Power Supply Voltage:	
DC:	18 to 32 VDC Regulated
AC:	24 V Regulated RMS(+10/-20%),47-63 Hz
Power Supply Current:	200 mA (max)- Enabled 150 mA (typ)- Enabled 30 mA (typ)- Disabled
Remote Read Output:	100 mA. max. load, non-inductive
Visual Indicators	
DS1:	Sensor Enabled
DS2:	Valid Read
Temperature Range	
Operating:	-40 to +55 degrees C
Non-operating:	-55 to +85 degrees C
Dimensions	
PCB:	4.0 x 4.4 x 1.1 inches
Enclosure:	?
Weight:	
PCB:	0.25 lbs. (0.12kg)
In Enclosure:	?

SECTION 2 INSTALLATION

2.1 INTRODUCTION

This section contains information for unpacking, inspection and installation. Installation includes power and signal wiring as well as mounting of the Reader itself.

2.2 UNPACKING AND INSPECTION

If the shipping carton is damaged or shows evidence of abusive handling, inspect the Reader for visible damage including dents, scratches, etc. If the unit appears damaged, contact the carrier and RFID, Inc. Sales or Customer Service Departments immediately. Keep the shipping and packaging material for the carrier's inspection. RFID, Inc. will arrange for repair or replacement of the damaged unit without waiting for the claim settlement with the carrier.

2.3 INSTALLATION SUMMARY




Figure 2-1 Installation Summary

Basically there are 3 sets or pairs of wires to consider, Power and Ground, Signal and Signal BAR, Enable and Enable BAR. These can be organized into 3 sets of 2 conductor cables, 1 set of 2 conductor and 1 set of 4 conductor cables, or 1 set of 6 conductor cable. Section 2.6 details these options and references cables by approved and recommended manufacturer part number.

Connect SIG and SIG BAR outputs from TB1 - 1 and 2 to Interface inputs SIG and SIG BAR using #20 - #28 AWG twisted pair wire. If used, connect shield to TB1 - 3, leave unconnected at other end.

OPTIONAL. Note: EN and EN BAR connections are used for multiplexing systems on Reader Model 1885(E) and Interface Model 2022(E). They are wholly unnecessary when using a Simplex system, Model 1880 unless you want to be able to disable the Combo Reader from time to time via command from the Interface. Connect EN and EN BAR inputs at TB2 - 1 and 2 to Interface outputs EN and EN BAR. If used, connect shield to TB1 - 3, leave unconnected at other end. Remove J1 for remote operation.

Select power source. Leave off while making connections:

AC - Connect AC power source to TB2 - 3 and 4.
Remove J2.

DC - Connect DC+ to TB2 - 3.
Connect DC- (GND) to TB2 - 5.
Install J2.

CAUTION!

Failure to remove the shorting jumper from J2 when operating with an AC power source will cause permanent damage to Reader circuitry. The Reader is normally supplied with the shorting jumper installed on J2 (DC operation).

2.4 POWER REQUIREMENTS

The Reader may be powered from regulated or linear, AC or DC power sources having the following characteristics:

Voltage DC:	Voltage Range:	18 to 32 volts
	Ripple:	100 mv p-p (max.)
Voltage AC:	Voltage Range:	24 v RMS (+10%, -20%)
	Frequency:	47-63 Hz
Current:	Operating:	200 mA. (max.)
		150 mA. (typ.)
	Disabled:	30 mA (max.)

RFID, Inc. can provide transformers and power supplies suitable for use with the Model 1880. If you provide your own power supply, it is recommended that you **avoid switching power supplies**. These supplies produce electromagnetic interference (EMI) that **WILL** interfere with the operation of the Combo Reader.

The Combo Reader assembly can operate from grounded or floating supplies. It may operate from a separate ground reference with respect to the Interface or host computer.

2.5 AC/DC POWER SELECTION

The Combo Reader contains an on-board bridge rectifier for conversion of floating AC power input to DC. For operation with DC input, this full-wave bridge can be bypassed with jumper J2.

AC Operation - Select the full-wave bridge by removing shorting jumper J2 from the printed circuit board.

DC Operation - Bypass the full-wave bridge by connecting both of J2's pins together with the shunt provided.

2.6 POWER CONNECTIONS

Power wiring should be connected to terminal strip TB2 using #20 to #28 AWG insulated, stranded wire. The power source should be turned off while making connections to the Combo Reader. Wires should be stripped approximately 3/8 of an inch. Tinning of these ends is recommended.

AC Supply: Connect AC power inputs to TB2 locations 3 and 4 that are marked AC/DC+ and AC.

Since AC has no polarity, pins 3 and 4 are interchangeable. TB2 location 5 (GND) is left unconnected and may be used as a DC ground reference if a floating supply is used. Be sure jumper J2 is removed before applying AC power.

DC Supply - Connect the positive DC input to TB2 location 3 (AC/DC+) and the DC return to TB2 location 5 (GND). TB2 location 4 (AC) is left unconnected. Reverse polarity can cause permanent damage so verify connections before applying power.

2.7 SIGNAL CABLING

For best performance, signal connections should be made with shielded, twisted pair cable. If the signal wires are combined in the same cable with the power and remote enable wires, then they should be separately shielded. The following cables are recommended for general use:

<u>APPLICATION</u>	<u>CABLE DESCRIPTION</u>	<u>PART NUMBERS</u>
Signal Only	2 Conductor paired cable #22 AWG w/foil shield Polyethylene & PVC 60 degrees C	Belden 8761 Columbia C2514 Manhattan M13226 RFID, Inc. PN 214-2202-00
Signal and Remote Enable Or Signal and Power Input	4 Conductor paired cable 1 pr. 22 AWG w/ foil shield 1 pr. 22 AWG unshielded Polypropylene & PVC 60 degrees C	Belden 8724 Alpha 2464 Manhattan M4451 TELSOR PN 214-2204-00
Signal Power, and Remote Enable	6 Conductor paired cable 2 pair 24 AWG w/foil shield 1 pair 22 AWG unshielded PVC, 80 degrees C	Belden 8786 Manhattan M14477 TELSOR PN 214-2206-00

Signal outputs are connected from terminal strip (TB1) on the Combo Reader to the SIG and SIG BAR inputs on the selected Interface. Wires should be stripped approximately 3/8 of an inch and tinned. The SIG output from the Combo Reader (TB1-2) connects to the SIG input on the Interface. The SIG output (TB1-1) connects to the SIG input on the Interface. If shielded cable (recommended) is used, the shield should be connected on one end only. It is recommended to connect the shield to the Combo Reader SHLD connection (TB1-3) and leave the other end floating. It is acceptable to connect the shield to the Interface and leave it floating on the Combo Reader. Over short distances or in environments that are free of electromagnetic noise the shield may be omitted.

DO NOT CONNECT THE SHIELD TO BOTH THE COMBO READER AND INTERFACE!

2.8 REMOTE ENABLE CABLING

Combo Reader operation may be controlled from an Interface or remote unit via the enable inputs (EN, EN BAR) at TB2 locations 1 and 2. Disabling the Combo Reader shuts off the Antenna's 148 kHz transmissions and reduces current draw to 30 mA (max). If the remote enable feature is not used, a shorting jumper must be placed across J1 and the EN/EN BAR inputs may be left unconnected. The shunt overrides the remote control and continuously enables the Combo Reader regardless of the EN/EN BAR inputs. The Model 1880 is normally supplied with the shorting shunt installed.

The remote enable feature can be used by some Readers by directly connecting the Interface EN output to the Reader EN input and the Interface EN output to the Reader EN input. Interfaces with this feature have ENABLE and DISABLE commands. Multiplexing Interfaces use this output to control Reader multiplexing and may not be compatible with the remote enable feature. Check the Interface to determine if it provides remote enable requirements.

To enable the Combo Reader remotely, a custom interface may be designed to provide the following characteristics:

ENABLED STATE: Differential Voltage = +3V (min) to +15V (max) into 500 OHM Load.

DISABLED STATE: Differential Voltage = +0.5V (max) to -5V (min) into High Impedance Load.

Differential voltage is measured from the EN to the EN terminal. That is, a +3V differential voltage means that the EN terminal (TB2 Pin 1) is 3.0 volts above the EN terminal (TB2 Pin 2). The remote enable circuit on the Combo Reader is an opto-isolator with a 470 ohm, .5 watt current limiting resistor in series. 5 mA is required to turn on the isolator. The following 2 control schemes are available for remote control:

SOURCE: Connect EN to Ground.
Connect EN input to the output of a logic device capable of sourcing 5 mA minimum.

Set EN to 0 volts to disable the Combo Reader.
Set EN to +5 to +12 volts to enable the Combo Reader.

SINK: Connect EN to +5 to +12 volts.
Connect EN input to the output of a logic device capable of sinking 5 mA minimum.

Set EN to 0 volts to enable Combo Reader.
Set EN to EN voltage to disable Combo Reader.

2.9 ANTENNA CONNECTIONS

This section intentionally left blank.

2.10 MOUNTING CONSIDERATIONS

The Combo Reader's operations can be affected by metal in close proximity. A high concentration of metal can distort or block fields created by the Antenna as well as absorb some of the energy it creates. For the Model 1880 Reader, the following guidelines should be used in determining mounting locations:

- Operation is not significantly affected by small isolated metal objects such as screws or other hardware.
- Large conductive areas such as metal plates should be kept at least half the Antenna's diameter, about 4 inches, from the Antenna.
- The impact on Reader operation is primarily a function of the area enclosed by the conductor. That is, a closed loop of wire of a given area can have nearly the same impact as a solid sheet of metal of the same area.

Standard anti-static precautions should be observed when handling 1880 Combo Readers outside of enclosures.

2.11 EXTERNAL INTERFERENCE

Since the Model 1880 transmits and receives electromagnetic fields, it is susceptible to interference from external sources of intentional and unintentional electromagnetic radiation. At its frequency of operation, the effect of external sources falls off rapidly with distance. The operation of the unit may be degraded by lower level sources of interference within 20 feet or so of the Combo Reader and higher level sources up to 100 feet away. The following items should be given consideration when operating the Combo Reader:

- Unshielded CRT's should be kept at least 20 feet from the Combo Reader to reduce the effect of the deflection yoke magnetic field. Orientation of the screen to the Combo Reader can have an affect on the exact distance of the interference. Try turning the screen, or changing its Hz settings at which it operates.
- Signal lines from the Combo Reader should always be run through shielded twisted pair cable.
- Power input lines should be well filtered and free of switching spikes caused by thyristors, SCR's, etc. which create interference across a broad spectrum of frequencies.

2.12 WARRANTY

RFID, Inc. products are warranted against defects in materials and workmanship for one (1) year from date of shipment. RFID, Inc. shall, at its option, either repair or replace products that prove to be defective and are returned with freight prepaid to RFID, Inc.'s plant within the warranty period. The foregoing warranty shall not apply to defects resulting from abuse, misuse, accident, alteration, neglect or unauthorized repair or installation. RFID, Inc. shall have the right of final determination as to the existence and cause of the defect.

THE WARRANTY SET FORTH ABOVE IS EXCLUSIVE AND NO OTHER WARRANTY, WHETHER WRITTEN OR ORAL, IS EXPRESSED OR IMPLIED. RFID, Inc. SPECIFICALLY DISCLAIMS THE IMPLIED WARRANTIES OR MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

The remedies provided herein are Buyer's sole and exclusive remedies. In no event shall RFID, Inc. be liable for direct, indirect, special, incidental or consequential damages, (including loss of profits) whether based on contract, tort, or any other legal theory.