



INSTALLATION AND OPERATING MANUAL

FOR

SIMPLEX SERIAL READER INTERFACE

MODEL 4000 Series
MODEL 4000E Series

SIMPLEX SERIAL READER WRITER INTERFACE

MODEL 5000 Series
MODEL 5000E Series



Version 05/08

TABLE OF CONTENTS

SECTION 1 - GENERAL INFORMATION	PAGE
1.1 INTRODUCTION.....	3
1.2 DESCRIPTION.....	4
1.3 SPECIFICATIONS.....	4
1.4 PRODUCT ACCESSORIES.....	5
 SECTION 2 - INSTALLATION	
2.1 INTRODUCTION.....	6
2.2 UNPACKING AND INSPECTION.....	6
2.3 POWER REQUIREMENTS.....	6
2.4 ANTENNA/READ HEAD INSTALLATION.....	8
2.5 MOUNTING CONSIDERATIONS.....	8
2.6 EXTERNAL INTERFERENCE.....	8
2.7 SERIAL INTERFACE CONNECTIONS.....	9
 SECTION 3 - OPERATION	
3.1 INTRODUCTION.....	11
3.2 APPLICABLE DOCUMENTS.....	11
3.3 DATA PROTOCOL.....	11
3.4 ISSUING COMMANDS TO THE READER.....	11
3.5 ISSUING COMMANDS.....	12
3.6 RESPONSES FROM THE READER.....	13
 4.0 WARRANTY.....	 14

LIST OF FIGURES AND TABLES

FIGURE 2-1 THE MODEL 4000.....	7
TABLE 2-1 I/O CONNECTIONS – J3.....	9
TABLE 2-2 PIN FUNCTIONS.....	10
TABLE 2-3 BAUD RATE SELECTION.....	10

SECTION 1 GENERAL INFORMATION

1.1 INTRODUCTION

This manual provides information pertaining to the installation and operation of the Model 4000 and Model 5000 Series Reader/Interface or Model 4000E and Model 5000E (the E signifying enclosure). Formally the Series consists of 4 models:

Model Number	Part Number	Voltage	Memory
4000E-RO	800-0086-02	12 VDC	16 Character
4001E-RO	800-0085-02	24 VDC	16 Character
4002E-RO	800-0086-00	12 VDC	8 Character
4003E-RO	800-0085-00	24 VDC	8 Character
4004E-RO	800-0086-04	12 VDC	32 Character
4005E-RO	800-0085-04	24 VDC	32 Character
5000E-RW	800-0085-01 800-0085-07	24 VDC	8 Character
5001E-RW	800-0085-03	24 VDC	16 Character
5002E-RW	800-0085-05	24 VDC	32 Character
5003E-RW	800-0086-01	12 VDC	8 Character
5004E-RW	800-0086-03	12 VDC	16 Character
5005E-RW	800-0086-05	12 VDC	32 Character

Where RO designates Reader Only and RW designates Reader Writer.

For simplicities sake any time the Model “4000” or “5000” is mentioned throughout this manual, assume all Models are being talked about unless specifically noted otherwise. As they stand above, these Models represent a PCB packaged. The letter “E” indicates inclusion of an enclosure with Antenna cable and power wiring. These products are also available as a PCB only for packaging into OEM applications or your electrical box.

1.2 DESCRIPTION

The Model 4000 and 5000 provides a half-duplex asynchronous bit serial data stream that will interface to equipment compatible with RS-232-C specifications. The Reader/Interface is configured as Data Terminal Equipment (DTE). The Model 4000 Reader/Interface provides an excitation signal to an external Antenna to electro-magnetically power a passive Tag, otherwise known as a Transponder or Label. The response from the Tag is sensed, amplified, filtered and demodulated by the Reader/Interface to determine the data stored in the Tag. The unit operates with many differing Antenna styles available from RFID, Inc.

The Reader/Interface contains circuitry to process Tag information as contained in the RFID, Inc. family of Tags. An error detection algorithm provides error free operation. All messages are transmitted in printable ASCII characters.

The Model 4000 operates as both a transmitter and receiver of RF signals. The unit provides a low frequency electromagnetic field at 148 KHz to activate an RFID, Inc. tag in the vicinity of the Antenna/Read Head field. Once the Tag is energized, it modulates the field in accordance with data contained in the Tag's eeprom chip. Receiving a return signal of 37 KHz from the Tag, the unit processes this information and relays it for use by a host computer, process controller or display and storage device. In addition to all of the above, the Model 5000 has the ability to send a re-programming message that updates or changes the Tag's programmed data.

1.3 SPECIFICATIONS

Communication Protocol:	Half-Duplex, DTE, RS-232-C	
Signal Lines:	TxD, RxD, CTS, RTS	
Data Transfer Rate:	1200-19200 baud	
Data Format:	8 bits, 1 stop bit, no parity	
Processing Speed:	8 Character Models	23.4 ms @ 9600 baud
	16 Character Models	46.7 ms @ 9600 baud
	32 Character Models	93.4 ms @ 9600 baud
Error Rate:	Less than 1 in 100,000,000,000,000 readings	
Connectors:	Antenna:	Angle entry terminal strip
	Power and Data:	12 contact Locking header, 0.1" centers
	Valid Read Output:	2 contact Locking header, 0.1" centers
Read Distance:	Up to 36" (Tag and Antenna dependent)	
Write Distance:	Planar coil Tags, nearly 98% of read range	
	Ferrite coil Tags (Tag Model ending in an "M") 60% of read range	
Operating Frequency:	148 KHz (transmit)	37 KHz (receive)

Temperature Range:	
Operating:	-40 to +55 C
Non-Operating:	-55 to +85 C
Power Supply Voltage:	12 VDC (8-14) or 24 VDC (18-32), Model dependent
Power Supply Current:	12 VDC Models: 250 mA (typ), 350 mA (max) 24 VDC Models: 400 mA (typ), 500 mA (max)
Dimensions:	Enclosure: 4.8" L x 4.8" W x 2.2" H, clear lid
Weight:	2.6 lbs. (full system)

1.4 PRODUCT ACCESSORIES

<u>Part Number</u>	<u>Model/Description</u>
720-0009-00	PS220 Power Supply, 12 VDC/500 mA
720-0008-00	PS230 Power Supply, 24 VDC/600 mA
719-0013-00	5100 Medium Prox Antenna
719-0013-01	5101 Small Prox Antenna
719-0015-00	5110 Hockey Puck Antenna
719-0016-00	5120 10.5" Tubular Antenna
730-0005-12	5100A1 Antenna Cable
102-0011-00	Insulated Wire w/o enclosure, 5.5" x 7.5"
719-0024-00	4' x 2' Extended Range Antenna
719-0026-00	Flat Pack Antenna, 7" x 7"
719-0027-00	Flat Pack Antenna, 12" x 12"
719-0025-00	Flat Pack Antenna, 21" x 17"
719-0086-00	Custom Slim Line Flexlink Conveyor Antenna
800-0050-00	Antenna Tuner

SECTION 2 INSTALLATION

2.1 INTRODUCTION

This section contains information for unpacking, installing and configuring the unit. Installation includes power and signal wiring, as well as matching and connecting the Model 4000 or 5000 to the Host Computer or Terminal. The unit is simple to use and install. It requires no alignment or adjustments and needs no special precautions or other consideration. The Model 4000 may be mounted in a variety of ways to suit the particular application and equipment. If, however, the enclosure is mounted vertically, the preferable orientation would be with the glands down (note Figure 2-2).

2.2 UNPACKING AND INSPECTION

If the shipping carton is damaged or shows evidence of abusive handling, inspect the Interface for visible damage including dents, scratches, etc. If the unit appears damaged, contact the carrier and RFID, Inc. Sales or Customer Service Departments immediately. Keep the shipping and packaging material for the carrier's inspection. RFID, Inc. will arrange for repair or replacement of the damaged unit without waiting for the claim settlement with the carrier.

2.3 POWER REQUIREMENTS

For Model 4000E or 5000E, power cabling is provided through the cable gland and pre-connected at PCB address J3. For Model 4000, power connection must be accomplished by you the user via purchasing of a connector fitting the pins at J3. I/O pin assignments are detailed in Table 2-3.

The Reader/Interface must be powered from a regulated DC power source having the following characteristics:

12 VDC Models:	250 mA (typ), 350 mA (max)
24 VDC Models:	400 mA (typ), 500 mA (max)

RFID, Inc. offers a full line of power supplies suited to optimize the Model 4000's performance. The maximum operation current has been calculated for worse case operation so further power supply overrating is unnecessary. Additionally, the unit should be operated from a grounded supply that has the same ground reference as the Host Computer.

WARNING

The power source should be turned off while making any connections to the unit. It is recommended that the power source remain off anytime the circuit board is removed from its enclosure assembly




FIGURE 2-1 ENCLOSURE MOUNTING DIAGRAM

J1 - In order from right to left

B0, B1, B2 = serial rate selection at B0 thru B2

F0, F1 = unused, will offer a serial format (RS-422-A) selection in next released versions

Blank = unused

16/32 = number of Tag characters selection, ON for 32, OFF for 16

ELM = Modem Eliminator, must be ON

J2 - Connection for heat dissipation to Resistor and Heat Sink

J3 - Serial I/O and Power, sequence is right to left, see section 2.7

J4 - Relay output

TB1 - Antenna Connector, 1 & 2 are interchangeable, 3 is for a shield connection if used

LED - Solid light indicates power is on, blink indicates read has been achieved

2.4 ANTENNA/READ HEAD INSTALLATION

Connection for an external Antenna is provided at terminal block TB1 (angle entry terminal strip). A cable is already attached when ordering the Model 4000E or 5000E.

The 12' cable is custom and is part of the Antenna's attenuated circuit, therefore altering the length of the Antenna cable **will** affect read and write range between the Antenna and a Tag. It is estimated that cutting the cable in half will shorten read range by 5% and cutting it down to 2' will shorten read range by 15%. A shorter cable can be accommodated without losing read range by altering capacitance at the Model 4000 or 5000 PCB. Please ask us for such customization.

There is no polarity when inserting the wires into TB1, meaning either white or black wires can be installed into either screw terminal. The maximum wire size accommodated by TB1 is 14 AWG.

2.5 MOUNTING CONSIDERATIONS

The Model 4000/5000's Antenna operation and resulting read range can be affected by large metal objects in close proximity. These objects distort the field area created by the Antenna as well as absorb some of the energy it creates. The Model 5110 Antenna is specifically designed for metal mounting. The following guidelines should be used in determining mounting locations:

1. Antenna is not significantly affected by small isolated metal objects, such as screws or washers.
2. Large conductive areas such as metal plates, screens, etc., should be kept at least 3-3/4 inches from the Antenna.
3. The impact on Antenna operation is primarily a function of the area enclosed by the conductor. That is, a closed loop of wire having the same area as the antenna base can have nearly the same impact as a solid sheet of metal of the same area.
4. As a general rule of thumb, an Antenna may be spaced half its diameter from metal to regain full functionality.
5. There is truly only one way to discover how an Antenna will function in a heavy metal environment, install a system and test.

2.6 EXTERNAL INTERFERENCE

Since the Model 4000/5000 transmits and receives electromagnetic fields, it is susceptible to interference from external sources of intentional and unintentional electromagnetic radiation. At its frequency of operation, the effect of external sources falls off rapidly with distance. The operation of the unit may be degraded by low level sources of interference within 10 feet or so of the unit, and higher level sources up to 100 feet away. The following items should be given consideration when operating the Reader:

1. Unshielded CRT's should be kept at least 10 feet from the antenna to reduce the effect of the deflection yoke magnetic field.
2. Power input lines should be well filtered and free of switching spikes caused by thyristors, SCR's, etc., which create interference across a broad spectrum of frequencies.

2.7 SERIAL INTERFACE CONNECTIONS

The Model 4000/5000 provides Tag data output in either a serial RS-232-C output. The protocol for both is identified in Section 3.3 and the selection formats are listed below. The serial data transfer (baud) rate is 1200 to 19200. Signal connections for the Interface are provided at PCB address J3.

I/O CONNECTIONS - J3

<u>COLOR</u>	<u>PIN</u>	<u>RS232 FUNCTION</u>
	1	unused
	2	unused
	3	unused
	4	unused
GRN	5	CTS
YEL	6	RTS
BLK	7	TxD
RED	8	RxD
	9	unused
WHT	10	GROUND
	11	VDC
	12	GROUND

Sequence for J3 is from right to left whereby the farthest right pin is #1

TABLE 2-1

PIN FUNCTIONS

<u>SIGNAL NAME</u>	<u>DIRECTION</u>
RxD - Received Data	To Reader
TxD - Transmitted Data	From Reader
RTS - Request To Send	From Reader
CTS - Clear To Send	To Reader

If you are using a standard serial connector or have had one included with the delivery of your system, the following pin-outs apply:

<u>SIGNAL NAME</u>	<u>PIN NO.</u>	<u>DIRECTION</u>
TxD	2	From Reader
RxD	3	To Reader
GND	5	
RTS	6	From Reader
CTS	7	To Reader

Note: For part number 800-0085-07 the pin out is the same as above with the addition of pin 1 also being a ground connection.

TABLE 2-2

BAUD RATE SELECTION

<u>RATE</u>	<u>B0</u>	<u>B1</u>	<u>B2</u>
1200	ON	ON	ON
2400	OFF	ON	ON
4800	ON	OFF	ON
9600	OFF	OFF	ON
19.2	ON	ON	OFF

TABLE 2-3

The serial data transfer (baud) rate into or out of the unit is determined by the presence or absence of shorting shunts on J1, shunts B0, B1, B2, at power up or reset.

SECTION 3 OPERATION

3.1 INTRODUCTION

This section pertains to the operating information of the Model 4000/5000. It describes the data protocol, messages into and out of the unit, Antenna operating characteristics and other features of the unit's Tag reading capability.

3.2 APPLICABLE DOCUMENTS

EIA Standard RS-232-C August, 1969
RFID, Inc. Interface Specification 719-0059-021 or 719-0060-021

3.3 DATA PROTOCOL

The data protocol utilizes ASCII characters for all data from the Model 4000/5000 and all control functions from the host computer. Each message includes delimiters at the start and end of message. Delimiters used for messages from the Model 4000/5000 are Line Feed (<LF>) at the start of message and Carriage Return (<CR>) at the end of the message. For Commands into the Model 4000/5000, the start of message delimiter may be either Line Feed (<LF>) or a left hand bracket [and the end of message delimiter may be either Carriage Return (<CR>) or a right hand bracket].

This protocol allows the Model 4000/5000 to be connected to a variety of computer systems, printers and terminals. Since special ASCII control characters are avoided, software in the host computer can be written in higher level languages without the need for special device driver routines.

To command the unit, always use capital letters.

To test if installation is proper and complete, the words "RFID, Inc. Vx.x" will appear as the output response of the Model 4000/5000 at power up. Reception of this message by the host indicates at least one-way communication is functioning. To test communication from the host to the Model 4000, issue a Carriage Return (<CR>) and see if the Reader/Interface respond with a question mark (?).

Messages into the Model 4000/5000 are checked for validity in the following manner. Upon receipt of the start of message delimiter, any previously received and unprocessed message text is discarded and the message search is reinitialized. Upon receipt of the end of message delimiter, message characters received since the last start delimiter are processed, checked for validity and acted upon.

3.4 THE READER'S BUFFERED MEMORY

Before proceeding, it is important to understand how the Reader's memory functions. The Buffer will store and hold only 1 Tag read, the last read. Presenting a Tag to the Reader will fill the Buffer and the Reader will not re-report that Tag as long as it remains to be presented to the Reader. In actuality, the Tags continue to be read by the Reader, compared to the info in the Buffer, and if they equal the Tag will not be reported out the serial port a 2nd time. Removing the Tag from the Reader will result in a watchdog timer commencing and upon reaching a preset timeout of 2.5 seconds the Buffer will be cleared. Then the original Tag can be presented again and read a 2nd time.

Using the Buffer Reset, Initiate Self Test, and System Reset commands discussed below will also clear the Buffer and allow a Tag to be read a 2nd time without it having to leave the Reader's RF field.

3.5 ISSUING COMMANDS TO THE MODEL 4000/5000

All commands and data must be done in CAPS. All commands are preceded by an open square bracket, and ended by a closed square bracket or a carriage return. The Reader responds to the following commands:

B	Buffer reset	I	Initiate Self Test
D	Continuous Read Mode	R	Repeat Message
S	System Reset or discontinue continuous Read Mode/return to single Read Mode		

In addition to the above commands, the **Model 5000** offers the additional following commands:

[Wxxxxxxx]	Write command for an 8 digit Tag
[Wxxxxxxxxxxxxxxxx]	Write command for a 16 character Tag
[Wxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxx]	Write command for a 32 character Tag

where x equals a capital ASCII character or number.

When sending a command to the unit, host operation assumes connection to a dumb terminal or a PC in terminal emulation mode. For a clean, noise free background, using a DOS based program like Procomm is preferable and recommended.

SYSTEM RESET

Type this: [S]

The Model 4000/5000 completely reinitializes and clears all buffers. Upon recognition of this command, the unit will issue a response of "OK". Use this command to return to the Single Report Mode if the Continuous Report Mode [D] has been entered.

BUFFER RESET

Type this: [B]

This command clears the Reader's memory buffer, enabling it to report the same Tag twice. Upon recognition of this command, the unit will issue an "ACKNOWLEDGE" response of "OK".

REPORT DUPLICATE LABEL

Type this: [D]

This command enters the Reader into a Repeating Report mode. As long as a Tag is presented to the Reader, it will repeatedly be read and reported out the serial port, to the Read LED, and to the relay output. Upon recognition of this command, the unit will issue an "ACKNOWLEDGE" response of "OK". You can only exit this mode by resetting with [S] or by cycling power to the Reader.

INITIATE SELF TEST

Type this: [I]

This command initiates an internal self test, checking its own operating functions. This is much like cycling power except the power up message is not sent. A successful self test results in an "ACKNOWLEDGE" response of "OK".

REPEAT MESSAGE

Type this: [R]

The Model 4000/5000 repeats the previously transmitted message. Upon recognition of this command, the unit will issue one of two "ACKNOWLEDGE" responses. If the Reader Buffer is empty, Tag data of all zeros will be reported. If the Reader Buffer holds Tag data, that data will be reported.

3.6 RESPONSES RECEIVED FROM THE MODEL 4000/5000

TAG DATA

16 & 32 character Models read Tags programmed with an ASCII character format. Valid character programmable digits are 0-9, A-Z in caps, and most normal keyboard characters.

8 character Models offer Tag digits of 0-9 ABCD only.

Tag data reports are as follows:

32 Character Readers

<LF>xxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxx<CR>

16 Character Readers

<LF>xxxxxxxxxxxxxxxx<CR>

8 Character Readers

<LF>xxxxxxx<CR>

Where LF (Line Feed) and CR (Carriage Return) are ASCII characters, and x equals data.

POWER UP MESSAGE

Displayed: RFID, Inc. Vx.x

If anything other than this appears, then an error has occurred or the Reader has not Self Tested successfully.

ACKNOWLEDGE

Displayed: OK

Issued by the unit to indicate successful acceptance of a received command for those commands that send no other acknowledgement of reception.

NEGATIVE ACKNOWLEDGE

Displayed: ?

Issued by the unit upon the receipt of an unrecognized command, improper delimiter format, improper number of data characters for associated command, or illegal data character value error.

4.0 WARRANTY

RFID, Inc. products are warranted against defects in materials and workmanship for one (1) year from date of shipment. RFID, Inc. shall, at its option, either repair or replace products that prove to be defective and are returned with freight prepaid to RFID, Inc.'s plant within the warranty period. The foregoing warranty shall not apply to defects resulting from abuse, misuse, accident, alteration, neglect or unauthorized repair or installation. RFID, Inc. shall have the right of final determination as to the existence and cause of the defect.

THE WARRANTY SET FORTH ABOVE IS EXCLUSIVE AND NO OTHER WARRANTY, WHETHER WRITTEN OR ORAL, IS EXPRESSED OR IMPLIED. RFID, Inc. SPECIFICALLY DISCLAIMS THE IMPLIED WARRANTIES OR MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

The remedies provided herein are Buyer's sole and exclusive remedies. In no event shall RFID, Inc. be liable for direct, indirect, special, incidental or consequential damages, (including loss of profits) whether based on contract, tort, or any other legal theory.